

Magnetic Concepts Corp.

Since 1989

© Magnetic Concepts Corp., 2007

Magnetic Whiteboards

Rol-a-charts®

Electronic Print Boards

Magnetic Accessories

Large Wall Panel System Installation

Instructions:

1. Lay out desired location and height for your wall system, and determine location of wall studs.
2. Determine location of bottom edge of board. Draw a level line on the wall at that height for the length of the board system.
3. Attach L-brackets along line, positioned between studs, using drywall anchors and 1 ¼" screws. Make sure the 1" side of L-bracket is against wall.
4. Place board on L-brackets. This will balance the board on the wall.
5. Place bottom piece of frame over board and brackets. Drill 1/8" holes through frame along the center channel, into studs. Secure frame and board to wall, using 2-½" screws.
IMPORTANT: If chalktray is used, drill holes ¼" above center channel on bottom frame piece only.
6. Continue attaching frame pieces, using same process as above, in order: Left, Top, Right.
7. On multiple board systems, the H-bar is simply slipped between the panels. You may apply some RTV sealer in the H-bar joints to prevent water or cleaners from leaking behind H-bar.

Do not use abrasive cleaners on panel surface. Clean only with Whiteboard Cleaner, Magnetic Concepts #90436 or equivalent.

Questions? Call 800-334-4245 for assistance.

Additional Supplies Part Numbers:

Whiteboard Accessory Kit
90437

Dry-Erase Markers
90431 (wide)

Whiteboard Cleaner
90436

Magnetic Eraser
90435

611 3rd Avenue SW Carmel, IN 46032 (800) 334-4245 (317) 580-4020
web www.bigboards.com email sales@magneticconcepts.com fax (317) 580-4024